INSTALLATION GUIDE

INTEGRITY PRODUCTS

Insulation Spacer

To avoid the possibility of galvanic corrosion occurring the spacer band and the process pipe should **NOT** come into direct contact with each other.

At a minimum, the insulation spacers should be installed at the 2, 4, 8 and 10 o'clock positions. This frequency should increase with the pipe/insulation size to maintain a consistent air gap and ensure the spacer band does not come in direct contact with the process pipe.

recommended install at install at r the end of each piece of the 2, 4, 8 insulation posi

install at minimum in the 2, 4, 8 & 10 o'clock positions spacer band and process pipe should not come into direct contact



1.800.673.0925 | info@integrity-products.com | integrity-products.com

ONLINE VIDEO http://l.ead.me/bauPyZ